

- (d) The front counter which is driven as long as the pressure element pointer slides over the raised part of the integrator drum. The counter indicates the amount of gas that has passed through the meter at base pressure. The name plate contains the following information:

Type, Serial number, Model, Pressure range, Atmos. pressure, Base pressure and Multipliers for front and rear counters.

The Base Pressure Index can be used in conjunction with any approved Volume and Pressure Gauge manufactured by the Canadian Meter Company Limited. For more detailed information refer to Technical Bulletin No. 2.

This approval notice supersedes N.R.C. Circular No. 1, dated May 26, 1933, and Approval Circular SD-GA.141. It covers not only the Base Pressure Indexes already in service which may not have Type or Model Designations but current production as well which does include these markings. The Model designation and the Pressure Spring designation are the same e.g. BP45.

E. F. Power

E. F. Power,
Chief, Electricity & Gas Division,
Standards Branch.

H. MacLean
MacLean,
tor,
ards Branch.

Ref: A-187E